

240sx96

YEAR: 1996 MAKE: Nissan MODEL: 240SX STYLE:

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white	+	ignition harness
STARTER	black/yellow	+	ignition harness
SECOND STARTER	black/white	+	ignition harness
IGNITION	black/red	+	ignition harness
ACCESSORY	white *5	+	ignition harness
POWER LOCK	lt. green/white	-	anti-theft module *1
POWER UNLOCK	brown	-	anti-theft module *1
PARKING LIGHTS +	red/blue *2		ignition harness
HEADLIGHTS	red/yel, red/blu *2	+	ignition harness
DOOR TRIGGER	red/white	-	harness in driver kick
TRUNK/HATCH PIN	red	-	anti-theft module *4
HOOD PIN	yellow/black	-	anti-theft module *1
FACTORY ALARM ARM	lt. green/red	-	anti-theft module *1
FACTORY ALARM DISARM	green/yellow	-	anti-theft module *1
TACHOMETER	yellow/red		ECM in passenger kick
BRAKE WIRE	red/green	+	brake switch
HORN TRIGGER	yellow/green	-	see notes
WIPERS	lt. green/red	-	ignition harness
LF WINDOW UP/DOWN	green - blue	A	auto down module *3
RF WINDOW UP/DOWN	red/wht - red/blk	A	switch in drivers door

NOTES:

*1 The anti-theft module is located just above hood release cable in the drivers kick panel. Other wires at the anti-theft module are:
12V-white/red, ignition-green, ground-black, left door pin-gray/red, right door pin-blue, panic(horn and high beam)-yellow/green.

*2 There are two (2) red/blue wires in the ignition harness, one is for parking lights and the other is for the right headlight.

*3 The auto-down module is in the drivers door just below the door open lever.

*4 If not equipped with an anti-theft module, the red wire is located in a harness at the left trunk hinge.

*5 When doing remote start, this wire must be isolated from the keyswitch with the accessory relay.